






# **MOUNTING INSTRUCTIONS**




| No. | Part number | Description                     | Qty |
|-----|-------------|---------------------------------|-----|
| 1   | 14022115    | Hyva – Oil tank SM -50L/35L -MF | 1   |
| 2   | 08102116    | Hyva - Air Breather             | 1   |
| 3.a | 14895930    | Return Filter Plate version     | 1   |
| 3.b | 14780306    | Return Filter Hose version      | 1   |
| 4   | DIN 7991    | Socket head bolt M8x30          | 4   |
| 5   | DIN 933     | Bolt M8x30                      | 2   |
| 6   | DIN 933     | Bolt M14x40                     | 4   |
| 7   | DIN127B     | Plain washer M8                 | 2   |
| 8   | DIN 127B    | Plain washer M14                | 8   |
| 9   | DIN 985     | Lock Nut M14                    | 4   |
| 10  | ISO 2009    | Counter screw M5x14             | 6   |

## 1. REMOVE THE COVER




## 2. MOUNT THE RETURN FILTER

### 2.a PLATE VERSION





## 2.b HOSE VERSION




## 3. ADD AIR BREATHER

Remove the sticker covering the air breather port











## 4. MOUNT THE OIL TANK TO THE CHASSIS



## I SUCTION HOSE



| No. | Description          | Qty. |
|-----|----------------------|------|
| 1   | LP hose              | 1    |
| 2   | Hose clamp           | 2    |
| 3   | Hose clamp chassis   | 1    |
| 4   | Hose pillar straight | 1    |
| 5   | Hose pillar 90       | 1    |
| 6   | Ball valve           | 1    |

